

Liteplan's emergency products are fitted with a charge indicating LED.

A Solid Green light indicates that the Battery Charge is healthy.

Self-Test and DALI emergency products are fitted with a Bi-Colour LED and basic with Green and indicate as follows:

- A **Solid Green light** indicates that the Battery Charge is healthy.
- A **Green Flashing light** indicates that the unit is in pre-commissioning mode, or there is either a Function or Duration Test in progress or that a test has taken place recently
- A **Red Flashing, Red Solid or Extinguished light** indicates that there is a fault on the unit.

Please refer to following chart below for more complete descriptions/fault indication:-



Model		Standalone/Exit Signs	D2N/T2N	Basic
<b>LED Indicates</b>				
Green Solid	Mains On No Fault			
	48h Pre-Commissioning	2.0s On 0.2s Off	2.0s On 0.2s Off	N/A
Green Flash	Function Test In Progress	0.2s On 2.0s Off	0.2s On 2.0s Off	N/A
	Duration Test In Progress	0.2s On 2.0s Off	0.2s On 2.0s Off	N/A
	Duration Test Passed	4.0s On 1.0s Off For 7 days		N/A
	Battery Fault	0.5s On 3.5s Off	0.5s On 3.5s Off	N/A
Red Flash	Lamp Fault	2x 0.5s On 2.5s Off	2x 0.5s On 2.5s Off	N/A
	Battery Temp. Fault	0.2s On 3.8s Off	0.2s On 3.8s Off	Off
LED Off	Fault	Off	Off	Off
Red/Green Alternate	DALI Mode Identification	0.5s Green 0.5s Red	0.5s Green 0.5s Red	
<b>Self-test only</b>				
Red/Green Alternate	Commissioning Test Time-out	N/A	2.0s Green 0.2s Red	N/A

NB: The above self-test time-out indicates that the control gear has not received permanent power for an uninterrupted period of 24 hours for 7 days. This only shows in self-test mode, not DALI.